

TDS: Transversely Deflecting Structure
FODO: Focusing - Drift - Defocusing - Drift
LPM: Longitudinal Profile Monitor